


### 3rd Floor – The Mille



The floor plan of the 11th floor is divided into three main sections:

- MB.11WR SONATA (Top Left):** Includes an Auto Opening Window, Service Riser, Riser, Cup'd, Server, and WC. It also features a fire alarm control panel (FACP) and a fire extinguisher (FEX).
- MB.11E VACANT (Top Right):** Includes a Service Riser, Riser, Cup'd, Server, and WC. It also features a fire alarm control panel (FACP) and a fire extinguisher (FEX).
- MB.11WF CITYCOM (Bottom):** Includes an Open Plan Office, Office, Rest Area, Kitchen, Reception, and various service areas like Elec., Lift, and Goods Lift. It also features a fire alarm control panel (FACP) and a fire extinguisher (FEX).

The plan also shows an Auto Opening Window, a Raki To 1 connection, and various fire and safety symbols.